

Lumino Guard Static White **Lumino Guard RGBW Combined Source**



INSTALLATION **GUIDE**

Important Note:

This installation guide is intended for reference purposes only. All installations should comply with local laws, regulations, and site-specific conditions. The recommendations provided are general guidelines and may require adjustments based on the actual site situation. Always consult a qualified professional for final installation decisions.

INSTALLATION INSTRUCTIONS

Lumino Guard

LUMINOSCAPE®
Architectural Lighting Solutions



WARNING:

- This product must be installed according to national and local electrical codes by a qualified individual familiar with the construction, operation, and associated risks.
- Failure to follow the installation instructions may result in serious injury or death.
- Disconnect power before installation or maintenance to avoid electrical shock.
- Do not exceed the rated voltage of the fixture.
- Do not install if the fixture, parts, or connectors are damaged.
- The fixture is rated IP67 and is suitable for outdoor inground applications, but **must not** be submerged in standing water beyond its ingress protection rating.
- Ensure proper drainage around the installation site to avoid water pooling or flooding that may compromise performance.
- Ensure that the connection box is IP68-rated and properly sealed to guarantee waterproofing.

CAUTION: Unauthorized modifications or repairs will void the warranty.

MAXIMUM LOAD CAPACITY PER RUN (Table 1)				
Series	Lumino Guard Static White		Lumino Guard RGBW Combined Source	
Input Voltage Range	100-277V, 50/60Hz		100-277V, 50/60Hz	
Max Power	18W (500mm), 36W (1000mm)		18W (500mm), 36W (1000mm)	
Power Factor	≥ 0.9 (@100V)		≥ 0.9 (@100V)	
Max. Power Linking	US (100V)	EU (220V)	US (100V)	EU (220V)
	500mm	105 nos.	58 nos.	105 nos.
	1000mm	30 nos.	30 nos.	55 nos.
Max run length is for interlink and leading cables (Fixtures not included)	40 Meters @US 60 Meters @EU		40 Meters @US 60 Meters @EU	

Remark:

- Please be aware that mounting screws and hex-head bolts are not included with your purchase. Installers will need to supply these items for installation. We recommend using stainless steel screws to prevent corrosion.
- The actual maximum daisy chain limit may vary based on the gauge of the leading cable and the specific installation conditions. The values provided are recommended guidelines and should be considered as such. Please ensure that all installations comply with local electrical codes and safety standards.

INSTALLATION INSTRUCTIONS


Lumino Guard

LUMINOSCAPE®
Architectural Lighting Solutions

HARDWARE INSTALLATION STEPS

STEP 1) Install Conduits and Cables:

Ensure the ground hold is properly prepared, including the installation of appropriate drainage piping and wiring conduit.




STEP 2) Test Drainage:

To confirm the drainage piping's effectiveness, ensure that the volume of water equivalent to the mounting box's capacity fully drains within a 30-minute period.

The proper drainage material must support the entire length of the mounting box to ensure it can withstand a resistance of 1000kg.

STEP 3) Install the Mounting Sleeve and Pour the Material (Concrete):

Before pouring the filling material, install the mounting sleeve on top of the drainage layers. Mount it with the Acrylic Support Insert provided by others. Surround it with concrete layers, and ensure it is leveled with the external finish.




INSTALLATION INSTRUCTIONS

Lumino Guard

LUMINOSCAPE®
Architectural Lighting Solutions


STEP 4) Remove the Supportive Formwork:

Remove the acrylic (or other mounting) accessories that maintain the shape of the mounting sleeve.




STEP 5) Feed Electrical Cable:

Feed the electrical cable through the conduit or make the necessary electrical connections to the incoming cabling outside of the mounting box. Once the electrical connections are complete, tuck the cable inside the box.



STEP 6) Fit the Luminaire:

Carefully fit the luminaire into the mounting box, ensuring that the cabling does not get trapped.



INSTALLATION INSTRUCTIONS

Lumino Guard

LUMINOSCAPE®
Architectural Lighting Solutions



WARNING:

- Ensure the **Lumino Guard** is properly earthed, and the AC power supply is equipped with a circuit breaker or fuse, ground fault protection, and a device to disconnect power for servicing or when the fixture is not in use.
- Disconnect all cables and the fixture from the power source completely before performing any maintenance tasks.
- Implement measures to prevent the accidental reconnection of power during maintenance.
- Confirm that the voltage and frequency specified on the product label match the local mains power supply before turning on the fixture.

IMPORTANT:

- All **Lumino Guard** models include a pre-installed power cable tail, suitable for direct connection to mains power.
- External connections must be enclosed in waterproof junction boxes or as required by local regulations, laws, or codes.
- Cable ends on **Lumino Guard** fixtures should be kept free from water or moisture, as the cooling process can create a vacuum that may draw moisture along the cable into the fixture.
- Ensure there is sufficient slack in the cable during installation to allow the fixture to be easily lifted for servicing without disconnecting the cables.

Wire Identification Schemes Table Static White:

Cable	Function	Core(US)	Wire Size	Core(EU)	Wire Size
Power (ON/OFF and TRIAC)	L (live)	Black	16AWG	Brown	1.3mm ²
	N (Neutral)	White	16AWG	Blue	1.3mm ²
	GND (Earth)	Green	16AWG	Yellow/Green	1.3mm ²
Power and Data Power Combined (0-10V and DALI)	L (live)	Black	16AWG	Brown	1.3mm ²
	N (Neutral)	White	16AWG	Blue	1.3mm ²
	GND (Earth)	Green	16AWG	Yellow/Green	1.3mm ²
	DIM+	Purple	22AWG	Purple	0.3mm ²
	DIM-	Pink	22AWG	Grey	0.3mm ²
	N/A	Yellow	22AWG	Yellow	0.3mm ²



WARNING (RGBW Combined):

- Ensure the **Lumino Guard RGBW** fixture is earthed, and the AC power supply includes a circuit breaker, ground fault protection, and a disconnect device for servicing or when not in use. Before connecting
- DMX cables, ensure all wiring meets DMX standards to prevent communication issues or damage. Disconnect the power supply and DMX signal entirely before any maintenance or troubleshooting.
- Verify that voltage, frequency, and DMX settings match the product label and local mains supply before
- powering on the fixture.
Confirm DMX address and control settings are accurate to prevent unintended lighting behavior.
- For DMX networks, ensure proper termination to avoid signal interference or reflections. (DMX Terminator)

Wire Identification Schemes Table (DMX or RDM):

Cable	Function	Core(US)	Wire Size	Core(EU)	Wire Size
Power and Data Power Combined	L (live)	Black	16AWG	Brown	1.3mm ²
	N (Neutral)	White	16AWG	Blue	1.3mm ²
	GND (Earth)	Green	16AWG	Yellow/Green	1.3mm ²
	DMX+	Purple	22AWG	Purple	0.3mm ²
	DMX -	Pink	22AWG	Grey	0.3mm ²
	DMX GND	Yellow	22AWG	Yellow	0.3mm ²

INSTALLATION INSTRUCTIONS

Lumino Guard


LUMINOSCAPE®
Architectural Lighting Solutions

CONNECTION SCHEMATIC

For daisy chain connections, please follow the illustrated diagram for proper connection. These fixtures are interconnected using a junction box.

IP68 Junction Box: (Prepared by customer)

A waterproof connection of at least IP68 must be established. When it comes to the junction box, we strongly advise using a suitable silicone gel to ensure effective sealing of the electrical connections within the box.



WIRING DETAILS (STATIC WHITE):

info@luminoscape.com

©2024 Luminoscape Lighting LG2404-in1


INSTALLATION INSTRUCTIONS

Lumino Guard

LUMINOSCAPE®
Architectural Lighting Solutions


Static White Wiring (ON/OFF, TRIAC) Schematic:

DAISY CHAIN LAYOUT (FIRST OR MIDDLE OF RUN)



Static White Wiring (0-10V, DALI) Schematic

DAISY CHAIN LAYOUT (MIDDLE OR END OF RUN)



INSTALLATION INSTRUCTIONS


Lumino Guard

LUMINOSCAPE®
Architectural Lighting Solutions


WIRING DETAILS (RGBW):

Static White Wiring (DMX, RDM) Schematic:

DAISY CHAIN LAYOUT (FIRST OF RUN)



DAISY CHAIN LAYOUT (MIDDLE OR END OF RUN)



INSTALLATION COMPLETION CHECKILIST

Checklist Category	Task	Completed (✓)
General Preparation	Verify all inground linear lighting components are present and undamaged (fixtures, sleeves, cables, etc.).	
	Confirm the AC power supply matches the voltage and frequency specified on the product label.	
	Ensure the circuit breaker or fuse, ground fault protection, and power disconnect device are installed.	
Mounting and Sleeve Preparation	Check that the mounting sleeves are installed correctly and remain undamaged after concrete pouring.	
	Ensure the fixtures are securely attached to the mounting sleeve using the mounting plate and screws.	
Drainage and Sealing	Test drainage by confirming the mounting box drains its water capacity completely within 30 minutes.	
	Verify the cable gland or conduit connection is tightly sealed to prevent water leakage.	
Electrical Connections	Confirm all power and data cables are securely connected and meet the recommended wiring standards.	
	Verify proper grounding of the fixture for safety and compliance.	
	Ensure DMX, 0-10V, DALI cables (if applicable) are terminated correctly to prevent signal interference.	
Safety and Testing	Confirm that power is disconnected before performing any adjustments or maintenance.	
	Test the installation for proper functionality, including DMX addressing and control settings (if applicable).	
	Inspect for any exposed wiring, loose connections, or mechanical stress on cables.	
Final Inspection	Ensure setback distances are applied correctly for optimal lighting performance.	
	Verify that the installation complies with all national and local electrical codes.	